




Carplay Touchscreen Manual Of **D5 MODELS**

V1.1


Zero Emissions. Zero Hassles. Zero Compromises.






TOUCHSCREEN MANUAL

Be familiar with vehicle features before attempting any operations.

TOUCHSCREEN INTRODUCTION



1. Blue tooth



Use the dial pad to enter the number you need to dial.

Tap button to delete the entered characters one by one.

Press and hold Button to continuously delete characters until all entered characters are deleted.

Tap button to dial the entered number.

You can also check the Recents and Contacts.

Get your phone connected.

Step 1: Power on the vehicle .

Step 2: Enable Blue tooth function on your cell phone.

Step 3: Search for "GeminicXXXXX" in your device list.

Step 4: Choose the device to establish the connections . now you can make phone calls or play music out of your phone.

Step 5: Go to Usable Device can check the connected devices. You can also turn on the 'Auto answer' and 'Auto load phonebook' function.

TOUCHSCREEN MANUAL

Be familiar with vehicle features before attempting any operations.

2. Radio



Store the sequence of stations:

When the automatic search station function **SCAN** is activated, the meter will automatically search for the local radio station, and the radio frequency number is stored in the local, convenient for users to call and manage. Up to 30 stations can be stored, and 6 preset stations are displayed in each column of the right window area. There are 5 bands that you can choose.

Storage station selection:

The two buttons **◀** and **▶** can be used to search the previous/next station of the preset station, respectively

Stereo logo:

If the current station broadcasts in stereo and the current signal meets the stereo decoding requirements, **ST ST** icon will be activated or you can manually activate or deactivate it by using the **ST ST** switch

Current station store page serial number:

If the station being played has a serial number greater than 6, say the seventh station, because only five preset stations can be displayed per band, the current station will be stored on the second band, so the current position will be displayed FM2, and so on if you are playing the thirteenth station, the current position will be displayed FM3. There are 30 stations can be stored, and 6 stations per band.

Radio frequency fine-tuning:

◀ ▶ Press and hold these two keys are mainly used to fine-tune the current radio frequency so that the signal demodulation is more accurate and the sound is clearer. Sometimes the frequency selected by the automatic search function may not be accurate, and this function can make up for the slight deficiency of the automatic search function


Local first:

LOC This button will give preference to local stations and ignore non-local stations (which, in theory, will have a weaker signal).

TOUCHSCREEN MANUAL

Be familiar with vehicle features before attempting any operations.

3.USB




Play your media (video&music&picture files).

Step 1: Copy the video & music files into a USB flash drive.

Step 2: Plug it to the touchscreen USB plug(PIC 2) .

Step 3: Click on USB icon to get access to the file you want to play .

Step 4: If there is no flash drive plugged in , you can't open the USB page.



When the Bluetooth connects to the phone, go to the "Sound Bar" menu, and the music you select to play on the phone will be displayed in this page.

Tap button to switch the currently playing music to the previous song in the song list.

Tap button to switch the currently playing music to the next song in the song list.

Press and hold button to continue fast forwarding the currently playing music until it reaches the end.

Tap button to enter the EQ function, then you can freely adjust the musical style, there are six styles that you can set. Also you can freely adjust the audio what you want.

Tap button to reset the adjustment to the factory set.

Be familiar with vehicle features before attempting any operations.

4.LED





Change the LED light color

Step 1: Go to "LED" menu.

Step 2: Click button to adjust the Horn LED mode, there are 8 kinds of color model: Red, Green, Blue, Yellow, Cyan, Purple, Gradient and with music. Also you can close the LED.

Step 3: Click icon to switch the light strip display mode.

Step 4: Press and hold icon can switch the rear strip display mode, it is the same color types as the LED light.



The audio light display consists of two parts: the ring light at the front and the long light strip at the rear. The light display modes can be changed by operating the positions shown on the touchscreen.

The following display modes are available for the front ring light and the rear strip light.

- ① Red: the light is constant red color.
- ② Blue: the light is constant blue color.
- ③ Yellow: the light is constant yellow color.
- ④ Green: the light is constant green color.
- ⑤ Cyan: the light is constant cyan color.
- ⑥ Grape: the light is constant grape color.
- ⑦ Rhythmic: the light has six colors cycling flashing.
- ⑧ The light does not light up.


The touchscreen displays the front ring light mode by default. Tap on the touchscreen icon to change the front ring light display mode. Press and hold the touchscreen icon to change the rear strip display mode.

Note: The display modes of the front ring light and the rear strip light are independent of each other, and can be toggled by long-pressing to switch the lights to the specified display mode.

TOUCHSCREEN MANUAL

Be familiar with vehicle features before attempting any operations.

4. Carplay





Connect the 'Carplay' function

Step 1: Go to "Settings" menu.

Step 2: Open the 'Carplay' on your phone, and find the corresponding name 'GeminicXXXX' to connect.

Step 3: The matching code will appear on the screen.


Step 4: Allow the pairing request and use 'Carplay' function.



TOUCHSCREEN MANUAL

Be familiar with vehicle features before attempting any operations.

4. Set



Set up your touchscreen.

Step 1: Go to "Settings" menu.

Step 2: Tap button to adjust the volume.

Step 3: Go to 'EQ' menu can adjust the music style what you want, See USB for details.

Step 4: Go to 'Microphone' menu to set Front or Rear.

Step 5: Go to 'General' menu.

Step 6: Go to 'Language' menu to choose English or Chinese.

Step 7: Go to 'Bluetooth' menu to set the function, you can open the Visibility, check the paired equipment and search the surrounding devices.


Step 8: Click button of the Speed unit to change the speed unit (mile/h or km/h)

Step 9: Go to 'Smartphone' menu can check connected equipment. Click these icon can turn on or turn off these function freely.

Step 10: Go to 'Brightness' menu to set the brightness what you need.

Step 11: Go to 'Radio' menu to set the Radio Area.

Step 12: Go to 'Serial&Version' menu to check the System version, SDK version and MUC version





HDK ELECTRIC VEHICLE

(CN office & factory): No. 36, North Tang'an Road, Dongfu Town,
Haicang District, Xiamen, China
E-mail: Sales@del-ev.com